



AMD Radeon™ R9 285 Series Graphics

User Guide / Owner's Manual

© 2014 Advanced Micro Devices Inc. All rights reserved.

Disclaimer

The information contained herein is for informational purposes only, and is subject to change without notice. While every precaution has been taken in the preparation of this document, it may contain technical inaccuracies, omissions and typographical errors, and AMD is under no obligation to update or otherwise correct this information. Advanced Micro Devices, Inc. makes no representations or warranties with respect to the accuracy or completeness of the contents of this document, and assumes no liability of any kind, including the implied warranties of noninfringement, merchantability or fitness for particular purposes, with respect to the operation or use of AMD hardware, software or other products described herein. No license, including implied or arising by estoppel, to any intellectual property rights is granted by this document. Terms and limitations applicable to the purchase or use of AMD's products are as set forth in a signed agreement between the parties or in AMD's Standard Terms and Conditions of Sale.

Trademarks

AMD, the AMD Arrow logo, AMD Athlon, AMD Catalyst, AMD CrossFire, AMD FirePro, AMD Radeon, Catalyst Control Center, and combinations thereof are trademarks of Advanced Micro Devices, Inc.

HDMI is a licensed trademark of HDMI Licensing, LLC.

Pentium is a registered trademark of Intel Corporation or its subsidiaries in the United States and other countries.

Linux is a registered trademark of Linus Torvalds.

Windows is a registered trademark of the Microsoft Corporation in the United States and/or other jurisdictions.

PCI Express and PCIe are registered trademarks of PCI-SIG.

Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.

Dolby Laboratories, Inc.

Manufactured under license from Dolby Laboratories.

Rovi Corporation

This device is protected by U.S. patents and other intellectual property rights. The use of Rovi Corporation's copy protection technology in the device must be authorized by Rovi Corporation and is intended for home and other limited pay-per-view uses only, unless otherwise authorized in writing by Rovi Corporation.

Reverse engineering or disassembly is prohibited.

USE OF THIS PRODUCT IN ANY MANNER THAT COMPLIES WITH THE MPEG ACTUAL OR DE FACTO VIDEO AND/OR AUDIO STANDARDS IS EXPRESSLY PROHIBITED WITHOUT ALL NECESSARY LICENSES UNDER APPLICABLE PATENTS. SUCH LICENSES MAY BE ACQUIRED FROM VARIOUS THIRD PARTIES INCLUDING, BUT NOT LIMITED TO, IN THE MPEG PATENT PORTFOLIO, WHICH LICENSE IS AVAILABLE FROM MPEG LA, L.L.C., 6312 S. FIDDLERS GREEN CIRCLE, SUITE 400E, GREENWOOD VILLAGE, COLORADO 80111.

Important Safety Instructions

Note: This product is for use only with compatible UL-listed personal computers that have installation instructions detailing user installation of this class of product.

Read all instructions before beginning installation. All safety and installation instructions should be read before the product is installed or operated.

Retain all instructions. Safety, installation, and operating instructions should be retained for future reference.

Heed all warnings. All warnings regarding the product and its operating instructions should be obeyed.

Use appropriate grounding.

Caution:

[Where applicable] For continued protection against the risk of electric shock and fire, install this accessory only in products equipped with a three-wire grounding plug, a plug having a third (grounding) pin. This is a safety feature. Do not remove the grounding pin of a three-pin plug.

Attach product securely. All product-securing screws or fasteners should be completely tightened in order to provide continuous bonding between the product and the PC chassis, as appropriate.

Contents

Chapter 1 Getting Started	1
1.1 System Requirements	1
1.2 Recording the Serial and Part Numbers	2
Chapter 2 Hardware and Software Installation	3
2.1 Installation Overview	3
2.2 Installing the Graphics Card	3
2.3 AMD Drivers and Software	5
Chapter 3 Display Configuration	7
3.1 Baseplate Connections	7
3.2 Display Adapters	7
3.3 Connecting Displays	8
3.3.1 Multi-Display Support	9
3.4 Using Adapters	9
Chapter 4 AMD CrossFire Technology	11
4.1 AMD CrossFire Overview	11
4.2 Installing Additional Graphics Cards for AMD CrossFire	11
4.3 Enabling and Configuring AMD CrossFire	11
Chapter 5 Using the Catalyst Control Center Software	13
5.1 Catalyst Control Center Overview	13
5.2 Starting the Control Center Software	13
5.3 Using the Catalyst Control Center Help System	14
Chapter 6 Reference	17
6.1 Troubleshooting	17
6.1.1 Graphics Card Installation Troubleshooting	17
6.1.2 HDTV Adapter Troubleshooting	18
6.2 Customer Care	19
6.2.1 Contact Information	19
6.2.2 Disclaimer	20
6.3 International Compliance Information	20
6.3.1 FCC Compliance Information (USA)	20
6.3.2 Industry Canada Compliance Statement (Canada)	21

6.3.3 CE Compliance Information (European Union).....	22
6.3.4 Electrical Safety.....	22
6.3.5 VCCI ITE Compliance Information (Japan).....	23
6.3.6 KC Certification Information (Korea).....	24
6.3.7 BSMI Certification Information (Taiwan).....	24
6.3.8 C-Tick (Australia and New Zealand).....	25
6.3.9 Product Environmental Compliance.....	25
6.3.10 Waste Electrical and Electronic Equipment (WEEE) Directive Compliance (European Union).....	26

Chapter 1

Getting Started

Before you begin installing your new AMD Radeon™ R9 285 Series graphics card (P/N: 102-C784/C766/C760xx-xx), make sure that you have the proper system requirements and have completed the required preinstallation tasks as outlined in this chapter.

1.1 System Requirements

The following are recommended system requirements for installation of the AMD Radeon™ R9 285 Series graphics card.

A second AMD Radeon™ R9 285 Series graphics card can also be installed and configured to work together using AMD CrossFire™ technology for added graphics performance. For more information, see [Chapter 4 AMD CrossFire Technology \(p. 11\)](#).

These recommendations apply to both single-card and dual-card installations:

- PCI Express®-based PC with at least one ×16 lane graphics slot available on the motherboard.

For dual-card installation, there must be enough room on the motherboard to provide at least one empty slot between the two graphics cards.

- AMD Athlon™ or Intel Pentium® 4 CPU.
- 600-watt or better power supply with two 6-pin PCIe® power connectors for the AMD Radeon™ R9 285 graphics card and an equivalent power supply with one 6-pin and one 8-pin PCIe power connector for the AMD Radeon R9 285X graphics card.

Certified power supplies are strongly recommended; for a list of certified power supplies, see ati.amd.com/certifiedpsu.

- A minimum of 8 GB of system memory.

For dual-card installation, a minimum of 16 GB of system memory is recommended.


- Windows® 8.1, Windows® 8, Windows® 7, or Linux® operating system (64-bit operating system is highly recommended).
- At least one display with digital input (HDMI™, DisplayPort, or DVI).
- A CD-ROM drive, keyboard, mouse, and display are required for software installation.
- A DVD drive is required for DVD playback.
- A Blu-ray drive and Blu-ray disc are required for Blu-ray playback.

1.2 Recording the Serial and Part Numbers

Write down the serial number and part number before installing the graphics card. The serial number and 102 part number on the graphics card are required for registration and free support. They are located on a sticker on the back of the card.

The emphasized numbers in bold are required for registration and free support.

Figure 1-1 Sample Serial and Part Numbers



Chapter 2

Hardware and Software Installation

This chapter details how to install your graphics card in your system as well as where to download associated software and drivers.

2.1 Installation Overview

Once you have determined that your system meets the minimum requirements, perform the following tasks to install your new graphics card. Detailed installation instructions are provided in the following sections.

1. If you are replacing an existing graphics card, uninstall the old graphics driver and software.

Note: If you are using a motherboard containing an on-board graphics solution and do not intend to use it as part of a multiple monitor configuration, disable it.

2. Turn off and disconnect your computer system.
3. If needed, remove any old graphics card(s).
4. Install the new graphic card.
5. Reassemble and connect your computer system and display(s).
6. Start the computer system and install the new AMD Catalyst™ drivers and configuration software.
7. Restart the computer system.

2.2 Installing the Graphics Card

1. Turn off the computer, monitor(s), and other peripheral devices.
2. Unplug the computer's power cord, and then disconnect all cables from the back of the computer.

Caution:

Wait approximately 20 seconds after unplugging the power cord before disconnecting a peripheral cable or removing a component from the motherboard to avoid possible damage to the motherboard.

3. Remove the cover to the computer's case.

Note: If necessary, consult the computer manual for help in removing the cover.

Caution:

Static electricity can seriously damage computer components. Discharge your body's static electricity by touching the power supply case or the metal surface of the computer chassis before you touch any components inside the computer's case to avoid damaging them.

4. Unscrew or unfasten and remove any existing graphics card from the computer, if necessary.

Warning:

Some graphics cards can get hot while operating. Wait approximately five minutes after turning off the computer before touching the card.

5. Locate the appropriate bus slot and, if necessary, remove the corresponding metal backplate cover(s). Make sure all internal cables are clear of the slot.

Note: If you cannot find a bus slot to match the card, you need a graphics card with the correct bus to match the motherboard.

6. Align the graphics card with the slot.
7. Make sure that all cables are moved out of the way and press the graphics card firmly in the slot until it is fully seated.
8. Fasten the graphics card securely to the back panel.
9. If your card requires supplementary power and must be connected directly to the power supply, locate the appropriate power connector cable(s) from the power supply and connect it (or them) to the graphics card's power connector(s).


The location of power connections may vary between models. They can be located on either the side or top of the card.

Tip: Before installing a card that requires a supplementary power connection, make sure your existing power supply has the required power connectors available.

10. If needed, install the second graphics card in the same manner as the first.

Note: Graphics cards must be separated by at least one empty expansion slot for proper air flow.

Figure 2-1 Dual-card Installation



11. Make sure no internal cables are interfering with components inside the computer (for example, a cooling fan), and then replace the computer cover.
12. Reconnect any cables that you have disconnected during installation, and then plug in the computer's power cord.
13. Turn on the monitor, and then the computer.

If you have properly installed the graphics card, the computer should start normally. Proceed to install the software and drivers for your AMD Radeon™ R9 285 Series graphics card.

2.3 AMD Drivers and Software

Drivers are small but important programs that enable an operating system to communicate with a piece of hardware, such as a graphics card.

When you install a new graphics card, you must also install the driver and configuration software the card requires to function properly.

You also need to install (or reinstall) your AMD Radeon drivers when you have reinstalled or upgraded your operating system or when you download updated drivers.

The latest drivers are available from AMD's Web site at <http://support.amd.com>.

Note: When reinstalling drivers, always uninstall any previous drivers that are on your system, even if they are for the same graphics card. Always start "fresh."

Chapter 3

Display Configuration


This section describes how to configure displays and lists available display connections for your graphics card.

3.1 Baseplate Connections

The following figure shows the display connections that are available on your AMD Radeon™ R9 285 Series graphics card.

Note: The baseplate may not appear exactly as depicted.

Figure 3–1 AMD Radeon™ R9 285 Series Display Connections



1	DisplayPort (DP++) connection. Carries video and audio signals to DisplayPort-compliant devices.
2	HDMI™ connection (Type A). Carries video and audio signals to HDMI-compliant devices.
3	Dual-link DVI-I connection. Provides video analog and digital signals.
4	Dual-link DVI-D connection. Provides video digital signals.

3.2 Display Adapters

Adapters/dongles can be used to connect displays not directly supported by the connection types available on the graphics card.

DisplayPort adapters come in three types:

- Adapter—Uses DisplayPort signals to transmit audio and video information between variants of the same connection type (for example, Mini DisplayPort to standard DisplayPort).
- Active dongle—Allows connection from a DisplayPort connection to a non-DisplayPort display using DisplayPort signals.
- Passive dongle—Allows connection from a DisplayPort connection to a non-DisplayPort display using non-DisplayPort signals.

Adapters/dongles that are not provided with your graphics cards can be purchased from AMD's Web site or through your local AMD resellers.

A list of compatible adapters/dongles for your graphics card can be found at <http://support.amd.com>.

3.3 Connecting Displays

The following table lists sample options for attaching displays to your graphics card. You can also use other types of adapters/dongles as long as they are compatible with your graphics card and display.

For best graphics performance and quality, always use native connections, when available.

Table 3–1 Display Configurations

Display Configuration	Connection Options
CRT (VGA) display	<ul style="list-style-type: none"> • DVI-D/DVI-I connection with DVI-D-to-VGA/DVI-I-to-VGA adapter • DisplayPort connection with DisplayPort-to-VGA connection
DFP (digital flat panel) display	<ul style="list-style-type: none"> • DVI-D/DVI-I connection and DVI-D/DVI-I cable • DVI-D/DVI-I connection with DVI-D-to-VGA/DVI-I-to-VGA adapter • DisplayPort connection with DisplayPort cable • DisplayPort connection with DisplayPort-to-DVI adapter
HDMI HDTV	<ul style="list-style-type: none"> • HDMI connection with HDMI cable • DVI-I/DVI-D connection with DVI-to-HDMI adapter • DisplayPort connection with DisplayPort-to-HDMI adapter

Once displays are connected to the graphics card, you can control how they are currently configured as well as how Windows® desktops appear on the displays using the Catalyst™ Control Center software application. Common configuration tasks include:

- Adding and removing displays
- Rotating displays
- Setting the main (primary) display
- Duplicating and extending desktops
- Arranging desktops

For more information, see [Chapter 5 Using the Catalyst Control Center Software \(p. 13\)](#).

3.3.1 Multi-Display Support

Your AMD Radeon™ R9 285 Series graphics card provides display functionality for up to six displays through AMD Eyefinity multi-display technology and any combination of the following:

- First three displays can be connected to any display connection on your graphics card.
- Additional displays must be connected to the DisplayPort connection either natively or through an active DisplayPort adapter.

Multiple DisplayPort displays can also be connected to a DisplayPort connection through a DisplayPort 1.2 Multi-Stream Transport (MST) hub or daisy-chain configuration.

Hubs and displays in this setup must be capable of the DisplayPort 1.2 standard.

The following table shows some examples of multiple display configurations; (A) indicates an active adapter is used and (P) indicates a passive adapter is used. Display abbreviations are DP = DisplayPort, dDVI-D = dual-link DVI-D, dDVI-I = dual-link DVI-I.

Table 3–2 Sample Display Configurations

Sample Display Configuration	dDVI-I Connector	dDVI-D Connector	DP Connector	HDMI Connector	Total Output
DP×6	-	-	6 displays via DP 1.2 MST hub or daisy chain	-	6
dDVI-I, dDVI-D, DP×2, HDMI	Native	Native	2 displays via DP 1.2 MST hub or daisy chain	Native	5
dDVI-I, dDVI-D, DP, HDMI	Native	Native	Native	Native	4
dDVI-I, dDVI-D, VGA, HDMI	Native	Native	DP to VGA (A)	Native	4
VGA, HDMI, HDMI	dDVI-D to VGA (P)	-	DP to HDMI (P)	Native	3

For additional configuration information, visit <http://www.amd.com/eyefinity>.

3.4 Using Adapters

The following procedure describes how to connect a display to your graphics card using an adapter.

1. Turn off your computer and display.
2. Plug the adapter into the connection from your AMD Radeon graphics card and tighten the thumbscrews (if there are any).
3. Connect your display's cable to the adapter and tighten the thumbscrews (if there are any).
4. Turn on your display first, then your computer.

Use the Control Center software application to configure the new display.

Chapter 4

AMD CrossFire™ Technology

Note: AMD CrossFire™ Technology features are available only for systems installed with more than one compatible AMD Radeon™ graphics cards and are intended for applications running in full-screen mode.

4.1 AMD CrossFire™ Overview

AMD CrossFire technology is designed to enhance the graphics quality and performance of 3D games and applications by combining the processing power of two or more AMD Radeon graphics cards, essentially creating a multi-GPU performance gaming platform. A typical AMD CrossFire setup involves two graphics cards.

For more information, visit the AMD CrossFire technology Web page at <http://sites.amd.com/us/game/technology/Pages/crossfirex.aspx>.

4.2 Installing Additional Graphics Cards for AMD CrossFire™

Before installing an additional graphics card, make sure that your system meets the recommended system requirements for AMD CrossFire technology. If needed, consult your system builder or OEM to confirm that your system has an adequate power supply.

Each AMD Radeon™ R9 285 Series graphics card must be separated by at least one empty expansion slot. For installation instructions, see [Installing the Graphics Card \(p. 3\)](#).

4.3 Enabling and Configuring AMD CrossFire™

Once all your graphics cards are properly installed, you can begin enabling and configuring AMD CrossFire technology support using the AMD Catalyst™ Control Center software application, which is a component of the AMD Catalyst software engine that can be downloaded from the Drivers and Support page at <http://support.amd.com>.

AMD CrossFire settings can be found on the **AMD CrossFire** page, which is located under the **Gaming** and **Performance** groups in both the Standard and Advanced views in AMD Catalyst Control Center.

When AMD CrossFire is enabled, the graphics processor in one of the cards acts as the primary processor; this card is known as the primary card. Graphics-rendering tasks are shared between all available processors to accelerate displays that are connected

to the primary card. By default, displays that are connected to other graphics cards are disabled but may be enabled by unlocking them.

Use AMD Catalyst Control Center to change your display setup and AMD CrossFire settings as needed. For more information, see the context-sensitive help system that comes with the application.

Chapter 5

Using the Catalyst™ Control Center Software

5.1 Catalyst™ Control Center Overview

The Catalyst™ Control Center software application contains settings for configuring and fine-tuning your AMD product. Use it to manage desktops and displays, optimize your graphics processor for enhanced 3D application and video quality, and configure your CPU for improved power savings or system performance. You can also use the performance tools in the application to monitor and manage clock speed and memory use for your graphics card to ensure that your AMD product is configured and running as efficiently as possible.

The application provides a Standard View for guided configuration and an Advanced View for quick and easy access to all available features and settings. It also provides a search feature for finding specific pages, as well as the ability to bookmark pages by pinning them within the application.

The following is a list of common configuration tasks that can be completed using the application:

- Adding and removing displays
- Rotating displays
- Setting the main (primary) display
- Duplicating and extending desktops
- Arranging desktops
- Managing 3D application and video settings
- Configuring AMD CrossFire™ technology settings (if applicable)

More information on the application and its available features are provided through the comprehensive Control Center help system.

Note: Feature availability varies between AMD products and operating systems.

5.2 Starting the Control Center Software

To start the Control Center software application in Windows®, use one of the following methods:

Table 5–1 Control Center Access Routes in Windows®

Access Route	Instructions
Windows Start Screen	<ol style="list-style-type: none"> 1. On the Windows Start screen, open App commands and then tap or click All apps. 2. Click the Control Center tile.
Windows Desktop	<ol style="list-style-type: none"> 1. Right-click anywhere on the desktop. 2. From the shortcut menu that appears, click the Control Center option.
Windows Start Menu	<ol style="list-style-type: none"> 1. Click Start on the Windows task bar. 2. Click All Programs followed by the Control Center option.
Windows Notification Area	<ol style="list-style-type: none"> 1. Right-click the Control Center icon in the Windows Notification Area. 2. From the shortcut menu, click the Control Center option.
Desktop Shortcut	If you chose to create a desktop shortcut to the Control Center application during the driver installation, double-click the shortcut.

To start the application in Linux®, type the command `amdcctl` in the terminal window.

To start the application with superuser privileges, do any of the following:

- Log on as a superuser before running the command `amdcctl`.
- Run the command `sudo amdcctl` and provide the superuser password when prompted.
- Run the command `amdxg-su -c amdcctl` and provide the superuser password when prompted.

Note: Certain Control Center settings can only be changed with superuser privileges.

5.3 Using the Catalyst™ Control Center Help System

The help system that is available with the Catalyst Control Center software application provides detailed usage information and tips for configuring your AMD product. The help system also provides conceptual information on the technologies that are available for your product.

Use the following steps to access the help system.

1. Open the Control Center application.
2. Choose one of the following options:
 - Set the mouse focus to the application window (by clicking the window) and press F1 on your keyboard.
 - Click the Help button (shown as a question mark) located in the titlebar of each page within the application.
 - Right-click the Control Center icon in the Windows taskbar notification area (system tray), and click **Help**.

The help system opens to provide context-sensitive help for the current page or general usage information.

Chapter 6

Reference

The following section offers troubleshooting tips and provides customer care, warranty, and compliance information.

6.1 Troubleshooting

Note: Some troubleshooting tips may not be applicable depending on the display options supported by and configured for your card.

6.1.1 Graphics Card Installation Troubleshooting

For more advanced troubleshooting information, contact AMD Customer Care at <http://support.amd.com>.

6.1.1.1 The graphics card doesn't fit any of the motherboard slots.

The graphics card needs to be exchanged for one with a bus that matches the motherboard.

For more information on bus types, see knowledgebase article [GPU-59: How to Install AMD Graphics Hardware](#).

6.1.1.2 The computer beeps and the boot process stops.

Make certain that the graphics card is properly connected to the internal power supply and the motherboard.

6.1.1.3 No display on power up.

Try these possible solutions:

- Verify that the monitor is connected properly to the computer and a power supply.
- Verify that the power supply meets the minimum system requirements.
- Reconnect all the hardware device cables that were removed during the installation of the graphics card.
- If any adapters or video switches are being used, remove them and connect the displays directly to the graphics card.
- Check the motherboard manufacturer's Web site for an SBIOS update.
- Turn off the on-board video.

- Install a different graphics card. If there are no display issues, then the graphics card in question may be defective.
- If your motherboard has on-board graphics capabilities, you may need to disable them. Consult your motherboard documentation for more information.

Note: Some manufacturers do not allow the on-board graphics to be disabled or to become the secondary display.

For more troubleshooting tips, see knowledgebase article [737-22472: How to Troubleshoot No Display on Re-start Issues](#).

6.1.1.4 The computer does not boot up properly.

Verify that the installation instructions were followed correctly.

Make certain that the graphics card is properly connected to the power supply and the motherboard.

For Windows® operating systems, restart your system in Safe Mode. Use Windows Device Manager to remove any graphics driver entries under **Display Adapters** and restart your system.

Check the system configuration utility for interrupt assignments.

6.1.1.5 During software installation on a Windows® OS, the screen goes blank.

The software is still installing. Wait 20–30 minutes to make sure the software has finished installing and then restart the computer.

6.1.1.6 Applications are hanging or there is no display after boot up.

Make certain that the graphics card is installed correctly and is properly connected to the motherboard and power supply (if applicable).

Verify that the power supply meets the minimum system requirements.

6.1.2 HDTV Adapter Troubleshooting

The following troubleshooting tips may help if you experience problems with HDTV.

More troubleshooting information can be found on the AMD Web site. Please visit <http://support.amd.com>.

6.1.2.1 There is a black border around the TV when using an HDMI™ connection.

Try adjusting the overscan/underscan of the TV. For more information, see knowledgebase article [GPU-72: Unable to Adjust a Digital Display to Match the Resolution of the Desktop](#).

6.1.2.2 There is no display on the TV.

The TV will not display anything until Windows starts; this may take several minutes.

Make sure the TV is set to YPbPr input.

6.1.2.3 DVDs will not play in high-quality modes.

For displays connected using an analog connection, playback of CSS-protected DVDs may be restricted to certain modes.

For displays connected using a digital connection, playback on certain DVD players may also be restricted if HDCP (high-bandwidth content protection) cannot be enabled. This restriction also applies to displays connected using active DisplayPort adapters.

6.1.2.4 The display appears tilted.

Consult the HDTV documentation.

6.1.2.5 TVs/monitors connected cannot be enabled.

Check individual connections to the TVs/monitors.

If TVs and/or monitors connected using DisplayPort adapters, passive dongles, or active dongles cannot be enabled, visit <http://www.amd.com/eyefinity> to check the connectivity options available for your graphics card and that your chosen configuration is supported.

For a list of AMD Eyefinity validated dongles, see <http://support.amd.com>.

6.1.2.6 Required display resolution is missing/unavailable in AMD Catalyst™ Control Center/AMD FirePro™ Control Center.

Make sure that:

- The desired resolution is supported for the display being used.
- The graphics driver has been properly installed.
- The connectors, cables, switches, and/or adapters connecting the display to the graphics card are compatible and correctly configured.

For more troubleshooting steps, see knowledgebase *GPU-10: Inability to Select a Specific Resolution for a Display Device in AMD Catalyst™ Control Center*.

6.2 Customer Care

The AMD Customer Care Web site has number of helpful resources, including a knowledgebase of FAQs and the AMD Radeon Workstation Graphics Web Ticket Submission Page.

The Web site is complimentary and available at all times. The address is <http://support.amd.com>.

6.2.1 Contact Information

If you experience difficulties with your AMD Radeon™ product, you can contact AMD Customer Care in the following ways.

The latest contact information and tips for faster service can be found on the AMD Global Technical Support page at <http://support.amd.com>.

6.2.2 Disclaimer

AMD Customer Care for Graphics Products will work to resolve your issue and help you to get your product up and running. If your issue is not resolved, our technicians will determine whether the difficulty you are experiencing is the result of the product, whether your product contains a defect, and whether your product is under warranty.

- AMD Customer Care is unable to assist with refunds, returns, or exchange-specific inquiries. If resolving the problem being experienced is critical to your decision to keep the product, it is your responsibility to ensure that you know and are within the period of time your reseller will allow for refunds, returns, or exchange.
- AMD is not responsible for any expense incurred accessing Customer Care. It is expected that customers will review the expense associated with the available support options and will choose the method that best meets their needs and budget.
- AMD Customer Care reserves the right to limit support options for products that are not registered or are reaching end of life.

6.3 International Compliance Information

This section details the worldwide compliance information for this product, which is manufactured to be compliant in the regions where it is sold.

AMD products are either Class A or Class B compliant and are indicated accordingly on the compliance label for each product. The following regulatory information applies to Class A and Class B products.

Any modifications to this device or its usage in an open chassis if not expressly approved by Advanced Micro Devices, Inc. may impact its compliance.

6.3.1 FCC Compliance Information (USA)

Class A

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are design to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case, the user will be required to correct the interference at his own expense.

Warning:

Changes or modifications to this device not expressly approved by Advanced Micro Devices, Inc. could void the user's authority to operate the equipment.

FCC Part 15, Subpart B, Class A

Class B

This product complies with FCC Rules Part 15. Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The use of shielded cables for connection of the monitor to the graphics card is required to ensure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC 15, Subpart B, Class B

For further compliance information:

Advanced Micro Devices, Inc.
1 AMD Place
P.O. Box 3453
Sunnyvale, CA 94088-3453
USA Tel: 408-749-4000

6.3.2 Industry Canada Compliance Statement (Canada)

Class A

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la Classe A est conforme à la norme NMB-003 du Canada.

Class B

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la Classe B est conforme à la norme NMB-003 du Canada.

6.3.3 CE Compliance Information (European Union)

Class A**Warning:**

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

EMC Directive 2004/108/EC

CISPR 22/EN 55022—Class A: Limits and methods of measurement of radio disturbance characteristics of Information Technology Equipment.

CISPR 24/EN 55024—Information Technology Equipment—Immunity Characteristics—Limits and Methods of Measurements

Class B

EMC Directive 2004/108/EC

CISPR 22/EN 55022—Class B: Limits and methods of measurement of radio disturbance characteristics of Information Technology Equipment.

CISPR 24/EN 55024—Information Technology Equipment—Immunity Characteristics—Limits and Methods of Measurements

6.3.4 Electrical Safety

Europe: The Low Voltage Directive—2006/95/EC

- EN 60950-1—Safety of Information Technology Equipment

USA/Canada:

- UL 60950-1 (Information Technology Equipment—Safety—Part 1: General Requirements)
- CSA C22.2 No. 60950-1 (Information Technology Equipment—Safety—Part 1: General Requirements)

International:

- IEC 60950-1 (Information Technology Equipment—Safety—Part 1: General Requirements)

To meet UL safety requirements, the computer's maximum room temperature should not exceed 40 °C.

This product complies with the PCI Express 300W Electromechanical Specification — please refer to the manufacturer for additional information. Other relevant input power data will also be available.



6.3.5 VCCI ITE Compliance Information (Japan)

Class A

この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

Translation:

This is a Class A product based on the standard of the VCCI Council. If this equipment is used in a domestic environment, radio interference may occur, in which case, the user may be required to take corrective actions.

VCCI V-3

Class B



この装置は、クラス B 情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

VCCI-B

Translation:

This is a Class B product based on the standard of the VCCI Council. If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

VCCI V-3

6.3.6 KC Certification Information (Korea)



Class A

A급 기기 (업무용 정보통신기기)

이 기기는 업무용으로 전자파적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며, 만약 잘못판매 또는 구입하였을 때에는 가정용으로 교환하시기 바랍니다.

Translation:

"Class A" Equipment (Business purpose info/telecommunications equipment)

As this equipment has undergone EMC registration for business purpose, the seller and/or buyer is asked to beware of this point and in case a wrongful sale or purchase has been made, it is asked that a change to household use be made.

KN22 and KN24

Class B

B급기기(가정용 방송통신기기)

이 기기는 가정용(B급)으로 전자파적합등록을 한 기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

Translation:

"Class B" Equipment (Household purpose info/telecommunications equipment)

As this equipment has undergone EMC registration for household purpose, this product can be used in any area including residential area.

KN22 and KN24

6.3.7 BSMI Certification Information (Taiwan)

Class A

警告使用者：
這是甲類的資訊產品，在居住的環境中使用
時，可能會造成射頻干擾，在這種情況下，
使用者會被要求採取某些適當的對策。

Translation:

This is a Class A Information Product, when used in residential environment, it may cause radio frequency interference, under such circumstances, the user may be requested to take appropriate countermeasures.



CNS13438

Class B



CNS13438

6.3.8 C-Tick (Australia and New Zealand)



ACMA — Australian Communications and Media Authority

- Radiocommunications Act 1992 (Australia)—per notices of section 182
- AS/ NZS CISPR 22

6.3.9 Product Environmental Compliance

This product may carry a marking similar to those below that indicates its level of compliance with China RoHS standards.



For information on China RoHS, EU RoHS, or EU REACH compliance, please refer to [Product Environmental Compliance](#) on the AMD Web site.

6.3.10 Waste Electrical and Electronic Equipment (WEEE) Directive Compliance (European Union)

This product was manufactured by Advanced Micro Devices, Inc.

